



BEYER HEADPHONE AND HEADSET SPARE PARTS

Spares for DT100, DT108, DT109 (applicable to all models unless stated). All parts are available in grey, a few items are also available in black (if no stock code is shown in the 'black' column, that item is not available in black). Neutral or concealed parts are also shown in the grey column and should be used for both grey and black headphones/headsets.

Code (Grey)	Code (Black)	Description	Ref on drawings
54-801	-	Ear loudspeaker, 400 ohms	1
54-852	-	Ear loudspeaker, 8 ohms	(1)
54-891	-	Ear loudspeaker, 50 ohms	(1)
54-892	-	Ear loudspeaker, 100 ohms	(1)
54-893	-	Ear loudspeaker, 200 ohms	(1)
54-894	-	Ear loudspeaker, 800 ohms	(1)
54-851	-	Ear loudspeaker, 2k ohms	(1)
54-802	54-781	Impedance disc, 400 ohms	(1)
54-854	54-782	Impedance disc, 2k ohms	(2)
54-855	54-783	Impedance disc, 8 ohms	(2)
54-856	54-784	Impedance disc, other impedances	(2)
54-803	-	Ear cushion	3
54-804	-	Foam infill	4
54-805	-	Housing, cable side, DT100	5
54-857	-	Housing, cable side, DT108/DT109	5
54-806	-	Housing, non-cable side, DT100, DT109	6
54-807	-	6 Pin socket, DT100	7
54-859	-	6 Pin socket, DT108, DT109	7
54-808	54-785	Junction box cover 'left'	8
54-860	-	Junction box cover 'right'	8
54-809	-	Headband cushion	9
54-810	-	Headband, DT100, DT109	10
54-861	-	Headband, DT108	10
54-811	-	Headband cable	11
-	54-786	Plastic rivet	12
54-813	-	Cable guide, DT100/DT109 (both sides), DT108 (cable side only)	13
54-830	-	Cable guide, DT108 (dummy pad side only)	13
54-814	-	Plastic pressure piece	14
54-815	-	Pressure spring	15
54-816	-	End stop	16
54-817	-	Label, 'Beyer Dynamic'	17
54-863	-	Label, DT100	17
54-864	-	Label, DT108	17
54-865	-	Label, DT109	17
54-818	-	Adhesive pad	18
54-819	-	Screw DT-1	19
54-820	-	Screw DT-2	20
54-821	-	Screw DT-3	21
54-823	-	Screw DT-5	23
54-825	-	Screw DT-7	25
54-826	-	Dummy pad, DT108 (different shape to illustration)	26
54-827	-	Side shell, DT108	27
54-828	-	Pre-amp PCB	28
54-829	-	Bracket to hold hardwired cable	29
54-831	-	Cover plate, 200 ohms	31
54-866	-	Cover plate, 600 ohms	(31)
54-832	54-787	Upper grille outer surround	32
54-833	-	Mic foam insert	33
54-834	54-788	Mic capsule, 200 ohms	34
54-867	-	Mic capsule, 600 ohms	(34)
54-835	-	Mic housing, lower	35
54-836	54-789	Screw cap	36
54-837	-	Insert, clearance taper bush	37
54-838	-	Insert, threaded taper nut	38
54-839	54-790	Mic boom	39
54-840	-	Mic cable standard	40
54-841	-	Mic cable DT109.11 type	41
54-842	54-791	Slotted disc cap	42
54-843	54-792	Knurled locking ring	43
54-844	54-793	Boom arm track disc	44
54-845	54-794	Quadrant disc	45
54-847	-	Pivot pin	47
54-848	-	Earshell pivot piece	48
54-849	54-795	Cam pin	49
54-850	-	Plastic pressure plate	50
54-853	-	Metal pressure plate	53
54-870	-	6 Pin plug (to fit item 7)	-
54-869	-	6 Pin plug retaining screw	-
54-871	-	K100-07 3 metre cable, straight, DT100, stereo jack	-
54-872	-	WK100-07 Cable, coiled, DT100, stereo jack	-
54-875	-	K100-00 3 metre cable, straight, DT100, unterminated	-
54-876	-	WK100-00 Cable, coiled, DT100, unterminated	-
54-873	-	K109-00 3 metre cable, straight, DT108, DT109	-
54-874	-	WK109-00 Cable, coiled, DT108, DT109	-

Main spare parts are held as stock items for DT48 and DT 220, see price lines. Other spares for these models, plus spares for other Beyer headphones and headsets are available to special order.