



HEADPHONE AND HEADSET SPARE PARTS

Spares for DMH220, DMH225 and SMH210

Ref. on drawing	Description	Code
1	Ear loudspeaker, 400 ohms (standard)	27-801
2	Mic capsule, 200 ohms	27-802
3	Cable bush	27-803
4	Cable ring, brass	27-804
5	Steel cable, straight (standard)	27-805
6	Headband cushion (DMH220, DMH225)	27-806
6	Headband cushion (SMH210)	27-837
7	Headband holder outer	27-807
8	Headband holder - inner	27-808
9	Screw, M2.2 x9.5 csk	27-809
10	Screw, M2.2 x6.5 csk	27-810
11	Headband, spring steel bow	27-811
12	Earphone cable	27-812
13	Bellows	27-813
14	Housing (left) (SMH210, DMH220, DMH225)	27-814
15	Housing (right) (DMH220, DMH225)	27-815
16	Sliding part, headband	27-816
17	Washer	27-817
18	Mic boom cable	27-818
19	Wire insert, mic boom	27-819
21	Mic housing, lower	27-821
22	Mic housing, upper	27-822
23	Mic housing, sleeve	27-823
25	Mic system, felt washer	27-825
27	Protective cloth for ear loudspeaker	27-827
28	Earpad, left	27-828
29	Earpad, right	27-829
28/29	Heavy duty earpad (all models)	27-839
30	Clip insert	27-830
-	Foam pad holder (SMH210)	27-834
-	Foam pad (SMH210)	27-835

Spares for DMH120

	Ear loudspeaker	27-841
	Microphone capsule	27-842
	Boom clamp	27-843
	Foam earpad	27-844
	Screw for boom clamp	27-845