



- 54-211 CANFORD ET-RS EARMOULD For acoustic eartube, small right
- 54-212 CANFORD ET-RM EARMOULD For acoustic eartube, medium right
- 54-213 CANFORD ET-RL EARMOULD For acoustic eartube, large right
- 54-214 CANFORD ET-LS EARMOULD For acoustic eartube, small left
- 54-215 CANFORD ET-LM EARMOULD For acoustic eartube, medium left
- 54-216 CANFORD ET-LL EARMOULD For acoustic eartube, large left

Instructions:

- 1 Choose the appropriate size and left or right handed earmould for your application. Earmoulds are marked on the top tip of the mould, for example 'ML', Medium Left. See fig 1.
- 2 Hold the earmould with the size mark facing and insert the elbow of the acoustic tube, see fig 1. When connected correctly the top tip of the earmould should be underneath the curve of the eartube, with tube inclined forward from the mould as illustrated.
- 3 Circle the eartube around the ear as illustrated in fig 2.
- 4 Insert the stub/canal portion of the earmould into the ear canal of the user.
- 5 Push the top tip, bottom tip and band into the users ear 'bowl'.
- 6 Earmould should be securely in place.

Acoustic eartubes using generic earmoulds:

- 54-231 CANFORD AET1 ACOUSTIC EARTUBE Transparent, with medium right earmould, no clip
- 54-2971 CANFORD AET1 ACOUSTIC EARTUBE Transparent, with medium left earmould, no clip
- 54-233 CANFORD AET3 ACOUSTIC EARTUBE Transparent, with medium right earmould, with clip
- 54-2973 CANFORD AET3 ACOUSTIC EARTUBE Transparent, with medium left earmould, no clip
- 54-227 CANFORD AET3 ACOUSTIC EARTUBE Black, with medium right earmould, with clip